

## **Changing the Combination of X-07 and X-09 Locks**

The purpose of this video is to demonstrate changing the combination of X-07 and X-09 locks.

To change to a new combination.

Enter the existing combination and retract the bolt.

Insert the change key into the holes on the back of the lock.

Dial to the left, or counterclockwise.

The change key symbol will appear.

The lock will never open when the change key symbol is displayed.

Enter the current combination, stopping on the last number.

Dial right until "SL" appears on the display.

Stop.

Dial left and stop on the numeral one.

If you pass it, continue dialing and it will reappear.

Dial right until "EC" appears on the display.

Stop.

Dial left and enter your new combination, as if opening the lock.

Stop on the last number.

Dial right until your combination starts flashing.

Stop.

Your new combination will flash three times with the X-07 but will only flash twice on the X-09.

At this time, "PO" will appear on the display.

Remove the change key.

"CC" will appear on the display.

Enter your new combination and open the lock.

Your new combination is now set.

Note, if the change key is removed at any time before "PO" appears, the lock will revert back to its old combination.